


QUICK SET-UP GUIDE


1000 HR-V IBB 28AH & 42AH

APPLICATIONS



UNBOXING :

Cut the nylon belt and lift the carton box from the top. Remove the polythene cover, foams and lift the UPS from the lower carton tray.




INSTALLATION :

Step 1

Turn on the battery circuit breaker

Step 2

Connect the application input plug to the UPS output socket, use 3-pin 6A 240 V AC plug before switching the UPS on.




INSTALLATION :

Step 3

Connect the UPS AC input power plug to socket before switching the UPS on (Use 3-pin 10A or 16A 240 V AC plug for 1 kVA).

**NEW ENERGY
TO POWER**




INSTALLATION :

Step 4


Press and Hold the ON/Mute button in the front panel for 2 seconds to switch the UPS on.

Display status




1. Power Switch
2. LCD Display

LCD Display




1. Input voltage
2. Output voltage
3. AC mode indicator
4. Battery mode indicator
5. Battery capacity indicator, flashing indicates low battery
6. Load level indicator; flashing indicates overload


✓ Do's



Keep at least 30 cms. clear distance between the rear panel of the UPS and the wall




Keep the UPS and its nearby area clean



Do dry your hands before operating the UPS.


✗ Don'ts



Do not eat or drink near the UPS area.



Do not pull any wires connected to the UPS



Do not put fingers into any slot

Scan the QR code
for warranty
registration



Scan the QR code
for unboxing
and quick setup video

